


# DUOBLOCK GAS BURNERS INSTALLATION, OPERATING AND MAINTENANCE MANUAL

## MODULATING OPERATION (MECHANICAL)



ECO 250  
ECO 300  
ECO 350  
ECO 400  
ECO 450  
ECO 500  
ECO 600  
ECO 700  
ECO 800  
ECO 900



**DEAR USER,**

**ECOSTAR ECO 250, ECO 300, ECO 350, ECO 400, ECO 450, ECO 500, ECO 600, ECO 700, ECO 800, ECO 900 Gas burners** are prepared and manufactured according to the latest technical developments and safety rules. It is easy to use for our customers.

We recommend that you read this manual and safety warnings thoroughly before the use of the device in order to ensure safe, cost effective and environmental-friendly use.

If you encounter any issue that is not explained clearly in this manual or you could not understand, please contact with our service department.

We thank you for choosing ECOSTAR brand.

Ecostar Gas Burners are manufactured in accordance with TS EN 676 +A2 standards.

This Operating Manual is an integral part of the burner and must be maintained in a plastic dossier and hung at a clearly visible place in the burner room.



**TERMO ISI SİSTEMLERİ SAN.VE TİC.A.Ş.**

Esentepe Mah.Milangaz Cad. No:75 K:3

Kartal Monumento Plaza  
Kartal/İSTANBUL/TÜRKİYE

Tel: +90 216 442 93 00

Fax: +90 216 370 45 03

[www.ecostar.com.tr](http://www.ecostar.com.tr)











e-mail:[servis@ecostar.com.tr](mailto:servis@ecostar.com.tr)

## CONTENTS

1.	WARNINGS .....	3
1.1.	Warning Symbols and Descriptions .....	3
1.2.	General Safety Rules .....	4
2.	TERMS OF WARRANTY .....	6
2.1.	Out of Warranty Conditions.....	6
3.	BURNER'S GENERAL FEATURES .....	7
3.1.	Purpose of Use and Work Limits of Burners.....	7
3.2.	Code Key.....	7
4.	TECHNICAL DATA .....	8
4.1.	Capacity Table.....	8
4.2.	Burner Dimensions .....	9
5.	INSTALLATION.....	11
5.1.	Burner Installation Picture .....	11
6.	COMMISSIONING .....	12
6.1.	General Controls.....	12
6.2.	Combustion Adjustment .....	13
6.2.1.	Pilot Ignition System .....	13
6.2.2.	PAL.....	15
6.3.	Air Pressure Switch Adjustment .....	18
6.4.	Servomotor Adjustment.....	19
6.5.	Emission Measurement.....	19
6.6.	Program Relay.....	20
6.7.	Photocell .....	26
6.8.	Gas Pass Equipment Required in Gas Line .....	27
6.9.	Gas Burner Ring Line.....	28
7.	MAINTENANCE .....	29
7.1.	Weekly Maintenance .....	29
7.2.	Monthly Maintenance.....	29
7.3.	Seasonal Maintenance.....	29
8.	TROUBLESHOOTING .....	30
9.	PERIODICAL FLUE GAS MEASUREMENT REPORT.....	31
10.	AFTER-SALES SERVICES.....	32
11.	NOTES .....	33

## 1. WARNINGS

### 1.1.Warning Symbols and Descriptions

Symbols	Symbol Descriptions
	Important information and useful hints.
	Warning of danger to life or property.
	Warning of electrical voltage.
	Product handling information.
P <sub>F</sub>	Impulse connection detecting combustion chamber pressure
P <sub>L</sub>	Impulse connection detecting combustion air pressure
P <sub>BR</sub>	Impulse connection detecting burner gas head
 CLEAN THE GAS BURNER. CLEAN GAS LINE. ЧИСТАЯ ЛИНИЯ ГАЗ.	"Clean the gas line" warning on gas line.
	Electric motor direction of rotation
   	Carry in an upright position. Fragile Item. Protect against water.

## 1.2. General Safety Rules

- All personnel engaged in installation, disassembly, commissioning, operation, control, maintenance and repair should have received the necessary training and fully read and understood this manual.
- No changes that might damage the safety of the burner unit must be made by persons and/or organizations on the burner unit.
- All operation, commissioning and installation works (except for burning adjustment) should be carried out when the burner is not operating and after disconnecting the power supply. Noncompliance with these rules may lead to serious bodily injuries and even death by electrical shocks or uncontrolled flame formation.
- Repairs concerned with safety elements should be carried out only by the manufacturing company.
- The device should never be used by children, mentally handicapped and inexperienced persons.
- Children must not be allowed to play with the device.
- Keep the device away from explosive and flammable materials.
- Device must intake air, ventilation and air discharge holes must not be closed.



Do not store any inflammable materials in boiler room.



Wear hearing protectors if there is noise in boiler room.



**In case of fire or other emergency;**

- Switch off the main switch
- Close the main fuel shut-off valve outside the plant.
- Take appropriate actions



The burner installation must be carried out in accordance with the instructions. Vibration can damage the burner and its components.



Keep boiler doors closed while starting burner and during burner operation.



Check combustion values to be correct by using flue gas analyzer at the whole adjustment range between minimum, full load, and ignition load.



Use lifting device or belt for lifting fan motor, if necessary



During the first commissioning of the burner or in case of any revision carried out in the electrical system or motor cables by any reason, direction of the fan rotation must certainly be checked by the authorized technical service.



For products that have not been commissioned or started more than 6 months, before activating the servomotor;

In gas and air dampers, servomotor and air damper connections must be checked to ensure that they are free running in spite of immobility and oil freezing.



## **BURNER ROOM**

Install the burner in a suitable room/floor with minimum external air openings and sufficient to ensure perfect combustion, in compliance with current regulations.

Never obstruct air openings of the burner room, burner fan intake vents or air ducts in order to prevent:

- a. The build up of toxic / explosive gas mixtures in the burner room,
- b. Combustion with insufficient air, resulting in hazardous, anti-economical and polluting operation.

The burner must be always protected from rain, snow and frost to prevent corrosion and paint deformations.

Keep the burner room clean and free of solid volatile substances, which could be sucked into the fan and clog the internal burner or combustion head air ducts.

## 2. TERMS OF WARRANTY

Main and auxiliary equipment and all components used in Ecostar gas burners are guaranteed for 1 year by TERMO ISI SİST. A.Ş starting from the date of commissioning under the maintenance, adjustment, operating conditions and relevant mechanic, chemical and thermal effects explained herein.



Please note that this warranty is only valid if the device(s) is commissioned and maintained by our authorized services.



Our company reserves the right to make any modifications on the product and all instructions thereof for improvement purposes.

### 2.1.Out of Warranty Conditions

- Any damage arising out of or in relation to customers' non-compliance to their responsibilities with regards to installation, commissioning, operation and maintenance,
- Any damage arising out of or in relation to commissioning, repairs and maintenance carried out by unauthorized services,
- Any damage that may occur during transportation or storage of the product,
- Not preserving the product in its original packaging until the installation stage,
- Incorrect and poor electrical connections, Failures due to incorrect voltage applications, frequent repetition of voltage fluctuations,
- Any damage that may occur as a result of incorrect fuel usage or, foreign substances in the fuel used or using of the product without any fuel,
- Any damage that may occur due to foreign particles entered into the product during installation and operation,
- Failures due to incorrect device selection,
- Any damage to unit due to natural disasters,
- Devices without any warranty certificates,
- Warranty Certificates without the stamp and signature of the authorized dealer or service,
- Devices with any falsification on the warranty certificate or without an original serial number.
- The risks during transportation of device under the responsibility of customer belong to the customer.
- Presence of misuse faults are indicated in the reports issued by authorized service stations or our authorized agent, dealer, representative or our factory in case of unavailability of authorized service stations.
- Customers may apply consumer protection arbitrator committee with regards to this report and request for an expert report.

### 3. BURNER'S GENERAL FEATURES

ECOSTAR gas burners are manufactured such that they operate in gas pressure of min. 100 mbar and max. 300 mbar., at -15%...+10% of nominal voltage, between the ambient temperature range of -15°C...+60°C and declared capacity and boiler pressure ranges with Natural Gas and Liquid Petrol Gas.


#### 3.1.Purpose of Use and Work Limits of Burners

- This product works at any load value equivalent to its max. capacity or covered by its capacity range;
  - In hot water and steam boilers,
  - In direct and indirect hot air generators,
  - Industrial appliances operating at temperature below 600 °C,
  - -15 °C...+60 °C ambient temperature range,
  - 1N 230 VAC/3N 380VAC /50 Hz feed voltage (-%15...+%10) values,
  - Max. 95% relative humidity,
  - In well-ventilated open and closed spaces compatible with protection class IP 40.



This device must never be operated with open flame!

#### 3.2.Code Key





## 4. TECHNICAL DATA

### 4.1.Capacity Table


BURNER TYPE	CAPACITY		NATURAL GAS CONSUMPTION
	Max. MW	Max. kcal/h	Max.Nm³/h
ECO-250.1	1,9	1.600.000	193,9
ECO-250.2	2,6	2.250.000	272,7
ECO-300.1	3,4	2.900.000	351,5
ECO-300.2	4,2	3.600.000	436,4
ECO-350.1	5,0	4.300.000	521,2
ECO-350.2	6,2	5.300.000	642,4
ECO-350.3	7,3	6.300.000	763,6
ECO-400.1	8,1	7.000.000	848,5
ECO-400.2	8,8	7.600.000	921,2
ECO-400.3	9,7	8.300.000	1006,1
ECO-450.1	11,5	9.900.000	1200,0
ECO-450.2	12,9	11.100.000	1345,5
ECO-450.3	14,5	12.450.000	1509,1
ECO-500.1	16,2	13.900.000	1684,8
ECO-500.2	17,8	15.300.000	1854,5
ECO-500.3	19,4	16.650.000	2018,2
ECO-600.1	20,8	17.900.000	2169,7
ECO-600.2	23,4	20.150.000	2442,4
ECO-600.3	25,0	21.500.000	2606,1
ECO-700.1	26,2	22.500.000	2727,3
ECO-700.2	27,3	23.500.000	2848,5
ECO-700.3	29,1	25.000.000	3030,3
ECO-800.1	32,1	27.600.000	3345,5
ECO-800.2	33,5	28.850.000	3497,0
ECO-800.3	35,2	30.250.000	3666,7
ECO-900.1	36,7	31.600.000	3830,3
ECO-900.2	39,2	33.750.000	4090,9
ECO-900.3	40,8	35.050.000	4248,5

$H_u$  Natural Gas =8250 kcal/Nm<sup>3</sup>

**Mechanical Modulating Burner-Modulation Ratio: Natural Gas 5:1**

## 4.2. Burner Dimensions

### ➤ Gas Asphalt Plant




	$\varnothing D$	L	E	H	F	C	K	S1	S2	S3	$\varnothing M1$	$\varnothing M2$	$\varnothing M3$	VL	DN
ECO 250 G 1	$\varnothing 296$	1850	650	875	500	700	325	250	300	340	$\varnothing 330$	$\varnothing 380$	$\varnothing 450$	570	DN50
ECO 250 G 2	$\varnothing 252$	1850	650	875	500	700	325	250	300	340	$\varnothing 330$	$\varnothing 380$	$\varnothing 450$	570	DN50
ECO 300 G 1	$\varnothing 268$	1850	650	875	500	700	325	300	350	385	$\varnothing 380$	$\varnothing 430$	$\varnothing 500$	570	DN65
ECO 300 G 2	$\varnothing 278$	1850	650	875	500	700	325	300	350	385	$\varnothing 380$	$\varnothing 430$	$\varnothing 500$	570	DN65
ECO 350 G 1	$\varnothing 298$	1900	675	900	550	740	350	350	410	450	$\varnothing 430$	$\varnothing 480$	$\varnothing 550$	670	DN80
ECO 350 G 2	$\varnothing 323$	1900	675	900	550	740	350	350	410	450	$\varnothing 430$	$\varnothing 480$	$\varnothing 550$	670	DN80
ECO 350 G 3	$\varnothing 343$	1900	675	900	550	740	350	350	410	450	$\varnothing 430$	$\varnothing 480$	$\varnothing 550$	670	DN80
ECO 400 G 1	$\varnothing 358$	1900	675	920	600	900	500	400	450	510	$\varnothing 480$	$\varnothing 530$	$\varnothing 600$	670	DN80
ECO 400 G 2	$\varnothing 373$	1900	675	920	600	900	500	400	450	510	$\varnothing 480$	$\varnothing 530$	$\varnothing 600$	670	DN80
ECO 400 G 3	$\varnothing 388$	1900	675	920	600	900	500	400	450	510	$\varnothing 480$	$\varnothing 530$	$\varnothing 600$	670	DN80
ECO 450 G 1	$\varnothing 408$	1950	675	960	640	1000	500	450	500	556	$\varnothing 580$	$\varnothing 630$	$\varnothing 700$	750	DN100
ECO 450 G 2	$\varnothing 433$	1950	675	960	640	1000	500	450	500	556	$\varnothing 580$	$\varnothing 630$	$\varnothing 700$	750	DN100
ECO 450 G 3	$\varnothing 453$	1950	675	960	640	1000	500	450	500	556	$\varnothing 580$	$\varnothing 630$	$\varnothing 700$	750	DN100
ECO 500 G 1	$\varnothing 483$	2500	760	1100	690	1000	500	500	550	608	$\varnothing 660$	$\varnothing 710$	$\varnothing 800$	870	DN125
ECO 500 G 2	$\varnothing 503$	2500	760	1100	690	1000	500	500	550	608	$\varnothing 660$	$\varnothing 710$	$\varnothing 800$	870	DN125
ECO 500 G 3	$\varnothing 523$	2500	760	1100	690	1000	500	500	550	608	$\varnothing 660$	$\varnothing 710$	$\varnothing 800$	870	DN125
ECO 600 G 1	$\varnothing 553$	2550	810	1100	690	1000	500	600	660	708	$\varnothing 740$	$\varnothing 792$	$\varnothing 860$	870	DN125
ECO 600 G 2	$\varnothing 568$	2550	810	1100	690	1000	500	600	660	708	$\varnothing 740$	$\varnothing 792$	$\varnothing 860$	870	DN125
ECO 600 G 3	$\varnothing 588$	2550	810	1100	690	1000	500	600	660	708	$\varnothing 740$	$\varnothing 792$	$\varnothing 860$	870	DN125
ECO 700 G 1															
ECO 700 G 2															
ECO 700 G 3															
ECO 800 G 1															
ECO 800 G 2															
ECO 800 G 3															
ECO 900 G 1															
ECO 900 G 2															
ECO 900 G 3															

**Contact The Sales Department**

Please Contact The Sales Unit For Special VL Sizes

➤ Gas Steam Boiler




	Ø D	L	E	H	F	C	K	S1	S2	S3	Ø M1	Ø M2	Ø M3	VL	DN
ECO 250 G 1	Ø264	1600	650	875	500	700	325	250	300	340	Ø330	Ø380	Ø450	320	DN50
ECO 250 G 2	Ø287	1600	650	875	500	700	325	250	300	340	Ø330	Ø380	Ø450	320	DN50
ECO 300 G 1	Ø307	1600	650	875	500	700	325	300	350	385	Ø380	Ø430	Ø500	320	DN65
ECO 300 G 2	Ø326	1600	650	875	500	700	325	300	350	385	Ø380	Ø430	Ø500	320	DN65
ECO 350 G 1	Ø346	1550	675	900	550	740	350	350	410	450	Ø430	Ø480	Ø550	320	DN80
ECO 350 G 2	Ø375	1550	675	900	550	740	350	350	410	450	Ø430	Ø480	Ø550	320	DN80
ECO 350 G 3	Ø389	1550	675	900	550	740	350	350	410	450	Ø430	Ø480	Ø550	320	DN80
ECO 400 G 1	Ø422	1600	675	920	600	900	500	400	450	510	Ø480	Ø530	Ø600	370	DN80
ECO 400 G 2	Ø430	1600	675	920	600	900	500	400	450	510	Ø480	Ø530	Ø600	370	DN80
ECO 400 G 3	Ø439	1600	675	920	600	900	500	400	450	510	Ø480	Ø530	Ø600	370	DN80
ECO 450 G 1	Ø492	1550	675	960	640	1000	500	450	500	556	Ø580	Ø630	Ø700	350	DN100
ECO 450 G 2	Ø525	1550	675	960	640	1000	500	450	500	556	Ø580	Ø630	Ø700	350	DN100
ECO 450 G 3	Ø539	1550	675	960	640	1000	500	450	500	556	Ø580	Ø630	Ø700	350	DN100
ECO 500 G 1	Ø591	2100	760	1100	690	1000	500	500	550	608	Ø660	Ø710	Ø800	475	DN125
ECO 500 G 2	Ø602	2100	760	1100	690	1000	500	500	550	608	Ø660	Ø710	Ø800	475	DN125
ECO 500 G 3	Ø619	2100	760	1100	690	1000	500	500	550	608	Ø660	Ø710	Ø800	475	DN125
ECO 600 G 1	Ø671	2150	810	1100	690	1000	500	600	660	708	Ø740	Ø792	Ø860	475	DN125
ECO 600 G 2	Ø684	2150	810	1100	690	1000	500	600	660	708	Ø740	Ø792	Ø860	475	DN125
ECO 600 G 3	Ø698	2150	810	1100	690	1000	500	600	660	708	Ø740	Ø792	Ø860	475	DN125
ECO 700 G 1															
ECO 700 G 2															
ECO 700 G 3															
ECO 800 G 1															
ECO 800 G 2															
ECO 800 G 3															
ECO 900 G 1															
ECO 900 G 2															
ECO 900 G 3															
<b>Contact The Sales Department</b>															
Please Contact The Sales Unit For Special VL Sizes															

## 5. INSTALLATION

### 5.1. Burner Installation Picture


#### Installation on the Boiler

- In the installation of the burner, please only use the installation materials supplied with the burner.
- Make sure that there are no gaps between the flange and boiler cover and ensure a full sealing by a gasket.



Make sure that, when installing burner at tree pass boilers, the end point of flame pipe should be on the same plane with the cover insulation material.

#### Asphalt Plant Application



## 6. COMMISSIONING

### 6.1. General Controls



Make sure to perform the following controls before commissioning the burner.


- Installation of the burner to the boiler is checked.
- Check the fuel line (Are the pipe diameters and the pipe installation correct?).
- Check energy input cables and voltages.
- Prior to operating the burner, control the boiler water level.
- Make sure water circulation system is turned on, and steam boiler and water feed pumps and boiler inlet - outlets are open.
- Is there electricity current?
- Is there gas?
- Has the boiler explosion lid been controlled?
- Is there sufficient air in boiler room?
- Has the air of the gas line been removed? Has a sealing test been made?

### Commissioning order



- Open the main gas valve; check max 300 mbar gas pressure from the manometer.
- Open operating switch on the burner panel.
- Switch on the modulating control switch.
- Switch automatic-hand switch to automatic.
- Check the temperature and pressure set values from the modulating control unit.
- Ignition will take place at the end of pre-purge process.
- 3 sec. later, the gas valve will be opened and combustion will occur.
- Flame control system will start flame control.
- In modulating burner, the burner goes into max. capacity according to the signal from the modulating control unit.
- When the boiler water temperature or steam pressure increase, the modulating control unit will cause burner to run with min. capacity.
- If the boiler water temperature or steam pressure increases despite the operation of burner with min. capacity, the modulating control unit will stop the burner.

## 6.2. Combustion Adjustment


### 6.2.1. Pilot Ignition System



**Pilot gas burner inlet pressure  $P_{max}=150-200$  mbar.  
Operation should be set to 80-100mbar.**



6.2.2.PAL



**Gas inlet pressure:35mbar**  
**Air pressure:17mbar**  
**Qmax:4,5m³/h**  
**Flame length:400mm**

ÖGE NO.	TANIM
1	TRANSFORMER BOX
2	PILOT LANCE TRANSFORMER BOX COVER
3	PILOT LANCE BODY
4	PILOT LANCE OUTER PIPE
5	FLAME STABILIZER
6	PILOT LANCE CONNECTING FLANGE
7	TURBULATOR
8	GAS PIPE INNER
9	GAS NOZZLE
10	TURBULATOR CENTERING PART
11	IGNITION ELECTRODE
12	MACHINE TYPE SOCKET
13	SOCKET BODY
14	FLAME MONITOR
15	SLEEVE
16	LABEL HIGH VOLTAGE
17	NATURAL GAS BALL VALVE
18	CASTING NIPPLE
19	LABEL
20	PURGER
21	IGNITION ARC SHAFT
22	RED LAMP
23	SOCKET
24	RECEIPT
25	PILOT LANCE CENTERING TRANSFORMER
26	BOLT
27	BOLT
28	BOLT
29	BOLT
30	SET SCREW
31	SET SCREW
32	O-RING
33	SPLIT PIN
34	WASHER
35	NUT





## Flame Monitor



### 03U1 Structure of the flame monitor

- 
- Electronic flame monitoring circuit,
- A relay with bipolar-bidirectional free contact output
- A bargraph or dotmatrix led set, displaying flame existence or level
- Buttons to set the delay time of the flame relay
- A display that displays “ON” when the flame is detected and “OFF” when the flame goes out
- The outer box is made of heat resistant plastic.





### 03A1 Structure of the flame monitor

- Electronic flame monitoring circuit,
- A relay with bipolar-bidirectional free contact output
- A operation lamp that is integrated to the electronic circuit which operates according to the flame's existence and strength,
- Buttons to set the delay time of the flame relay
- A display that displays "ON" when the flame is detected and "OFF" when the flame goes out
- The outer box is made of heat resistant plastic.
- 
- 



The controller device must never be opened or modified!

- The flame monitor must be installed and run by authorized staff only.
- The power supply must be turned off prior to removing the device from its socket
- Connection terminals must be checked after installation of cables

If any problem occurs with the device, our



### 6.3. Air Pressure Switch Adjustment




While the burner is working without any problem, the air pressure switch is adjusted to desired minimum pressure as follows.


- Unscrew the screw of the transparent cover and remove the cover.
- Turn the adjustment wheel in the direction to increase the pressure, note the pressure value at which the burner is failed.
- Set the pressure switch to a value 1 mbar lower than the pressure value at which the burner failed and close the pressure switch lid.
- It is recommended that this adjustment is carried out when the burner is at minimum load.

## 6.4.Servomotor Adjustment



 Servomotors drive air dampers, gas butterfly valve and oil regulator. With the help of servomotors electronic air and fuel ratio control is carried out, controlled by burner control.


- Static electricity can damage servomotor.
- Do not open servomotor. Do not interfere with or modify unit or equipment connected to it. It may damage servomotor or change burner settings.
- Completely isolate equipment from the main supply before performing any wiring changes in servomotor connection area.
- Check that wiring is in an orderly state.
- Protect equipment from condensation, water and ice.
- Fall or shock can adversely affect safety functions. Such servomotors may not be put into operation.


 Do not open servomotor. Do not interfere with. It may damage servomotor or change burner settings.

## 6.5.Emission Measurement

In emission measurements, the following values are accepted as reference according to TS EN 676 +A2 standard.

- $CO < 100 \text{ mg/ kWh}$
- $\%3 \leq O_2 \leq \%5$
- $NO_x < 170 \text{ mg/ kWh}$
- Excess air ratio  $1,2 \leq \lambda \leq 1,3$

 It is important for the boiler to be sealed in order to avoid incorrect measurements during emission measurements.

 Boiler temperature must be between 40 C° and 80 C° while making emission measurement in hot water boilers.

## 6.6. Program Relay

### ➤ LFL



#### Control sequence under fault conditions and lockout indication

In the event of any kind of fault, the sequence switch will stop and, with it, the lockout indicator.

The symbol above the indicator's reading mark gives the type of fault:


◀	No start	<ul style="list-style-type: none"> <li>• One of the contacts is not closed (also refer to «Preconditions for burner startup»)</li> <li>• Extraneous light</li> </ul> <p>Lockout during or after completion of the control sequence.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>– Flames that have not extinguished</li> <li>– Leaking fuel valves</li> <li>– Defect in the flame supervision circuit</li> </ul>
▲	Interruption of startup sequence	<ul style="list-style-type: none"> <li>• Terminal 8 has not received the OPEN signal from end switch «a»</li> <li>• Terminals 6, 7 and 14 remain live until the fault has been corrected</li> </ul>
P	Lockout	<ul style="list-style-type: none"> <li>• No indication of air pressure at the beginning of the air pressure check</li> <li>• Loss of air pressure after the air pressure check</li> </ul>
■	Lockout	<ul style="list-style-type: none"> <li>• Defect in the flame supervision circuit</li> </ul>
▼	Interruption of startup sequence	<ul style="list-style-type: none"> <li>• Terminal 8 has not received the positioning signal from auxiliary switch «m» for the low-fire position</li> <li>• Terminals 6, 7 and 14 remain live until the fault has been corrected</li> </ul>
1	Lockout	<ul style="list-style-type: none"> <li>• No flame signal on completion of safety time «TSA»</li> </ul>
2	Lockout	<ul style="list-style-type: none"> <li>• No flame signal on completion of the second safety time (flame signal of main flame with interrupted pilot burners)</li> </ul>
I	Lockout	<ul style="list-style-type: none"> <li>• Loss of flame signal during operation</li> </ul>

If lockout occurs any other moment in time between start and preignition not indicated by a symbol, the usual cause is a premature flame signal, that is, a faulty flame signal, caused for instance by a self-igniting UV tube.

Lockout indicator



LFL1... Serie 01



LFL1... Serie 02


a-b Startup sequence

b-b' Idle steps  
(with no contact confirmation)


b (b')-a Postpurge program


- If lockout occurs, the burner control can immediately be reset:
  - Do not press the lockout reset button for more than 10 seconds
- The sequence switch always returns to its start position first
  - After resetting
  - After correction of a fault which resulted in plant shutdown
  - After each power failure

During that period of time, power is only fed to terminals 7 and 9...11.
- Then, the LFL1... begins with a new burner startup sequence




➤ LME73











7105d102e/0814

Phase number of display		LED	Function
<b>7-segment</b>	<b>AZL2...</b>		
LOC	LOC	OFF	Lockout phase
<b>Standby</b>			
OFF	OFF	OFF	Standby, waiting for heat request
<b>Startup</b>			
P21	Ph21	Yellow	Safety valve ON, air pressure switch in no-load position Test if POC closed (timeout/lockout after 5 seconds) Actuator opens in CLOSE position
P22	Ph22	Yellow	Part 1: Fan motor ON Part 2: Specified time air pressure switch Message (timeout), stabilization air pressure switch
P24	Ph24	Yellow	Actuator travels to the prepurge position (timeout)
P30	Ph30	Yellow	Part 1: Prepurge time without extraneous light test *1 Part 2: Prepurging with extraneous light test (2.1 seconds)
P36	Ph36	Yellow	Actuator travels to the ignition load position (timeout)
P38	Ph38	Yellow	Pre-ignition time
P40	Ph40	Flashing yellow	Postignition time
P42	Ph42	Green	Flame detection
P44	Ph44	Green	Interval: End of safety time and fuel valve 1 ON
P50	Ph50	Green	Part 1: Interval: Fuel valve 1 ON and pilot valve OFF Part 2: Flame-out response time
<b>Operation</b>			
oP1	oP:P1	Green	Interval until load controller release and operation
<b>Shutdown</b>			
P10	Ph10	OFF	Home run
P72	Ph72	Yellow	Actuator travels in postpurge position (timeout)
P74	Ph74	Yellow	Postpurge time *2
<b>Valve proving</b>			
P80	Ph80	Yellow	Test space filling
P81	Ph81	Yellow	Test gas pressure
P82	Ph82	Yellow	Test space evacuating
P83	Ph83	Yellow	Test atmospheric pressure
<b>Safety shutdown phases</b>			
P01	Ph01	Yellow / red	Under voltage / over voltage
P02	Ph02	Yellow	Safety shutdown (e.g. open safety loop) → Lockout
P04	Ph04	Green / red	Extraneous light in standby
P90	Ph90	Yellow	Gas pressure switch-min open → Safety shutdown and startup prevention



## 6.7. Photocell

Check the photocell weekly. Clean the dust or fume stains on the glass of photocell by a dry cloth.


### ➤ QRA10



### ➤ QRA2




## 6.8. Gas Pass Equipment Required in Gas Line












<b>Pe &lt; 300 mbar Q&lt;1200kW</b>	<b>Pe &gt; 300 mbar Q&lt;1200kW</b>	<b>Pe &lt; 300 mbar Q&gt;1200kW</b>	<b>Pe &gt; 300 mbar Q&gt;1200kW</b>
1- Compensator	1- Compensator	1- Compensator	1- Compensator
2- Ball valve	2- Ball valve	2- Ball valve	2- Ball valve
3- Gas filter	3- Gas filter	3- Gas filter	3- Gas filter
4- Inlet manometer + valve	4- Inlet manometer + valve	4- Inlet manometer + valve	4- Inlet manometer + valve
8 – Multi-block (safety and operation solenoids)	5- Regulator	8 – Multi-block (safety and operation solenoids))	5- Regulator
10- max. gas pressure switch	6- Outlet manometer + valve	9- Sealing Control Set	6- Outlet manometer + valve
11- min. gas pressure switch	7- Safety discharge valve	10- max. gas pressure switch	7- Safety discharge valve
	8 – Multi-block (safety and operation solenoids)	11- min. gas pressure switch	8 – Multi-block (safety and operation solenoids)
	10- max. gas pressure switch		9- Sealing Control Set
	11- min. gas pressure switch		10- max. gas pressure switch
			11- min. gas pressure switch

## 6.9. Gas Burner Ring Line

GAS P&ID



	BALL VALVE
	MANOMETER PRESSURE GAUGE
	GAS FILTER
	REGULATOR
	RELIEF VALVE
	SELENOID VALVE GAS PRESSURE SWITCH MIN. - MAX.
	FLEX HOSE
	PILOT GAS REGULATOR
	GAS SELENOID VALVE

## 7. MAINTENANCE

### 7.1. Weekly Maintenance

Weekly maintenance is a routine cleaning and adjustment procedure which is performed to ensure smooth and continuous operation of the system. Burner components must be adjusted after each maintenance work in accordance with the instructions. Otherwise, the burner cannot be operated efficiently.

- Check the burner gas tip.
- If the fin spaces and surface of the diffuser are covered with particles and formed a layer, clean it with a wire brush.
- Clean heads of ignition electrodes. Check by performing manual ignition, adjust the distance between the ignition electrode and diffuser according to the adjustment instructions.

### 7.2. Monthly Maintenance

Monthly maintenance is a more comprehensive maintenance compared to weekly maintenance, where general checks of burner and peripheral components are performed to prevent possible faults. After completion of maintenance and adjustment processes, make sure to perform a combustion analysis.

- Clean the filters on the fuel line to the burner.
- Clean the surface of the diffuser.
- Clean flame pipe.
- Check all wiring points. Tighten loose connections.
- Clean the dust and layers accumulated on the fan and air valves.
- Check ignition electrodes. Adjust it if necessary. Check ignition cables and sockets.
- Perform cleanliness control of inside panel. Clean if necessary.
- Check all bolts of the burner. Tighten loose bolts.
- Check the burner gas tip.
- Check gas line pressure, it must be the same with the first adjusted pressure, otherwise burner load and emission values will also have changed.
- After starting the burner and adjusting air klappe, perform flue gas emission measurement and check if there is an ideal combustion.

### 7.3. Seasonal Maintenance

Comprehensive maintenance work when the burner is re-started after long periods of shut-down or interruptions. After completion of maintenance and adjustment processes, make sure to perform a combustion analysis.

- Check insulation resistance of electric motor.
- Make surface cleaning of ignition electrodes and porcelains. Replace cracked or broken porcelains.
- Clean air fan and clamps.
- Check the operating function.
- Check boiler thermostats.
- Check cleanliness of boiler inside and clean if necessary.

## 8. TROUBLESHOOTING

<b>Problem</b>	<b>Cause</b>	<b>Explanation-Suggestion</b>
Burner cannot be commissioned	Gas is cut or does not come	Gas valve might be closed. Open the valve.
	Fuse failure	Check burner power supply. The fuse on the main panel or the fuse on the burner might be tripped.
	Relay failure	Reset the thermal relay. Check adjustment of the thermal relay according to the current in motor label. If the failure is not removed, replace the thermal relay.
	Boiler thermostat, pressure switch failure	If there is a problem with the burner thermostats, pressure switches and steam tank this may be due to an unadjusted or faulty water level device; adjust it and if broken, replace it.
Flame appears and goes into failure mode.	Gas pressure error	Supply gas pressure might be low.
	Ionization electrode failure	Ionization electrode may be faulty or contaminated. Remove and clean.
	Program relay failure	Replace it with a new one.
Burner starts up, but fails after 10 seconds.	Air pressure switch adjustment	Air pressure switch might be adjusted to a high value. There may be dirt in the air pressure switch. Air pressure switch might be broken.
	Program relay failure	Replace it with a new one.
	Fan motor failure	Check fan motor coils, motor contactor and outlet from program relay.
Burner starts up, but fails after 30 seconds.	Gas valve, gas pressure drop	Gas valve might be closed. Supply gas pressure might be low. Check gas inlet manometer.
	Ignition electrode failure	Ignition electrodes might be misadjusted or ignition cables might have come out of their terminals. Adjust ignition electrodes with a distance of 3-5 mm. between them.
	Gas valve adjustment	Check the starting setting of the gas valve. Burner must be adjusted to sufficient start gas flow for its activation.
Boiler cover is overheating.	Sealing problem	Ensure sealing between the boiler cover and burner. If required, use insulating material between the boiler connecting flange and boiler cover.

### 9. PERIODICAL FLUE GAS MEASUREMENT REPORT

Fuel Consumption (m <sup>3</sup> /h)	CO (ppm)	O <sub>2</sub> (%)	CO <sub>2</sub> (ppm)	NO <sub>x</sub> (ppm)	Yield (%)	Flue Temp. (°C)	Date	Signature



## 10. AFTER-SALES SERVICES

Dear Customer,

We believe that providing a good service is as important as providing a good product. Therefore, we continue offering wide range of comprehensive services to our conscious customers.

For your suggestions, complaints and service requests

**Esentepe Mah. Milangaz Cad. No:75 K:3**

**Kartal Monumento Plaza**

**KARTAL/İSTANBUL/TÜRKİYE**

**Tel: 444 8 326**

**Fax: +90 216 370 45 03**

Factory Contact Details

**Türkgücü OSB**

**Bülent Ecevit Bulvarı No:11**

**ÇORLU/TEKİRDAĞ/TÜRKİYE**

**Tel: +90 282 685 44 80-81**

**Fax: +90 282 685 42 09**

Also you can contact with us:

**Web site : [www.ecostar.com.tr](http://www.ecostar.com.tr)**

**E - mail : [servis@ecostar.com.tr](mailto:servis@ecostar.com.tr)**



Please observe the following recommendations.

- Use the product in accordance with the principles of this manual.
- For any service demands regarding the product, please contact our Service Center from the abovementioned phone numbers.
- Upon your purchase, register your warranty certificate during installation.

